

**BOMBARDIER**



AIRPORT PLANNING MANUAL

To: Distribution

Subject: Dash 8 Series 400, Airport Planning Manual, PSM 1-84-13

This is Revision 4 of the Dash 8 Series 400, Airport Planning Manual, PSM 1-84-13, dated Dec 05/2014.

We recommend this letter of transmittal be retained for record purposes.





# AIRPORT PLANNING MANUAL

PSM 1-84-13

## **BOMBARDIER INC.**

Bombardier Aerospace Commercial Aircraft  
Customer Support  
123 Garratt Blvd., Downsview, Ontario  
Canada M3K 1Y5

Copyright© 1998 by Bombardier Inc. All rights reserved. No part of this work may be reproduced or copied in any form or by any means without written permission of Bombardier Inc.

# **BOMBARDIER**

**Initial Issue: Dec 21/1998**

**Revision 4: Dec 05/2014**

The information, technical data and the designs disclosed in this document ("the information") are either the exclusive property of Bombardier Inc. or are subject to proprietary rights of others. The information is not to be used for design or manufacture or disclosed to others without the express prior written consent of Bombardier Inc. The holder of this document, by its retention and use, agrees to hold the information in confidence. These restrictions do not apply to persons having proprietary rights in the information.

# Technical Publications

## Manual Change Request

**BOMBARDIER**

<b>TO: MCR FOCAL, TECHNICAL PUBLICATIONS</b> <b>BOMBARDIER AEROSPACE</b> <b>123 GARRATT BLVD.</b> <b>TORONTO, ONTARIO, CANADA, M3K 1Y5</b> <b>MAIL STOP: N42-25 FAX: (416) 375-4538</b> <b>E-MAIL ADDRESS: mcrfocal@aero.bombardier.com</b>		<b>Name of Airline:</b>
		<b>Bombardier Reference #:</b>
		<b>Date:</b>
<b>ALL fields marked with an asterisk * are required</b>		
<b>Contact Information</b>		
*Name:	*Corporation Name:	*Dept Name/Code:
Address:	City:	State/Province:
Postal Code / Zip:	Country:	*Telephone:
Mobile/Cell Phone:	Fax Number:	*E-Mail:
<input type="checkbox"/> I would like to receive notification of actions on this request. <b>NOTE: Responses will only be sent by electronic mail.</b>		
<b>Publication Information</b>		
*Aircraft Type:	*Aircraft Model:	*PSM/CSP:
*Publication Name/Revision:	*Media Type: <input type="checkbox"/> Paper <input type="checkbox"/> DVD <input type="checkbox"/> CD-ROM <input type="checkbox"/> IFLY	*Chapter/Section/Subject/Task (or) Page Block/Page Number:
Originator's reference number:	Impact on other programs:	
*Description of Change Request:		
Reason for change:		
Reference data provided: <input type="checkbox"/> Yes <input type="checkbox"/> No    Description:		

NOTE: Electronic submissions of MCRs are available on [www.iflybombardier.com](http://www.iflybombardier.com)

Oct 4/2013











**BOMBARDIER**  
AEROSPACE



AIRPORT PLANNING MANUAL  
LIST OF EFFECTIVE PAGES

<u>Chapter</u>	<u>Page</u>	<u>Date</u>	<u>Chapter</u>	<u>Page</u>	<u>Date</u>
Effective Pages	1	* Dec 05/2014		32	* Dec 05/2014
	2	* Dec 05/2014		33	* Dec 05/2014
Contents	1	* Dec 05/2014		34	* Dec 05/2014
	2	* Dec 05/2014		35	* Dec 05/2014
	3	* Dec 05/2014		36	* Dec 05/2014
	4	* Dec 05/2014		37	* Dec 05/2014
	5	* Dec 05/2014		38	* Dec 05/2014
	6	* Dec 05/2014		39	* Dec 05/2014
Chapter 1	1	* Dec 05/2014		40	* Dec 05/2014
	2	May 28/2001		41	* Dec 05/2014
Chapter 2	1	* Dec 05/2014	Chapter 3	42	* Dec 05/2014
	2	* Dec 05/2014		43	* Dec 05/2014
	3	* Dec 05/2014		44	* Dec 05/2014
	4	* Dec 05/2014		1	May 28/2001
	5	* Dec 05/2014		2	May 28/2001
	6	* Dec 05/2014		3	May 28/2001
	7	* Dec 05/2014		4	May 28/2001
	8	* Dec 05/2014		5	May 28/2001
	9	* Dec 05/2014		6	May 28/2001
	10	* Dec 05/2014		7	May 28/2001
	11	* Dec 05/2014		8	May 28/2001
	12	* Dec 05/2014		9	May 28/2001
	13	* Dec 05/2014		10	May 28/2001
	14	* Dec 05/2014		11	May 28/2001
	15	* Dec 05/2014		12	May 28/2001
	16	* Dec 05/2014		13	May 28/2001
17	* Dec 05/2014	14	May 28/2001		
18	* Dec 05/2014	15	May 28/2001		
19	* Dec 05/2014	16	May 28/2001		
20	* Dec 05/2014	Chapter 4	1	May 28/2001	
21	* Dec 05/2014		2	May 28/2001	
22	* Dec 05/2014		3	May 28/2001	
23	* Dec 05/2014		4	May 28/2001	
24	* Dec 05/2014		5	May 28/2001	
25	* Dec 05/2014		6	May 28/2001	
26	* Dec 05/2014		7	May 28/2001	
27	* Dec 05/2014		8	May 28/2001	
28	* Dec 05/2014		9	* Dec 05/2014	
29	* Dec 05/2014		10	May 28/2001	
30	* Dec 05/2014	Chapter 5	1	* Dec 05/2014	
31	* Dec 05/2014		2	* Dec 05/2014	
			3	* Dec 05/2014	

The asterisk (\*) indicates pages revised, added or deleted by current revision.

Series: 400



**BOMBARDIER**  
AEROSPACE

AIRPORT PLANNING MANUAL

<u>Chapter</u>	<u>Page</u>	<u>Date</u>	<u>Chapter</u>	<u>Page</u>	<u>Date</u>
	4	* Dec 05/2014		4	* Dec 05/2014
	5	* Dec 05/2014			
	6	* Dec 05/2014			
	7	* Dec 05/2014			
	8	* Dec 05/2014			
	9	* Dec 05/2014			
	10	* Dec 05/2014			
	11	* Dec 05/2014			
	12	* Dec 05/2014			
	13	* Dec 05/2014			
	14	* Dec 05/2014			
	15	* Dec 05/2014			
	16	* Dec 05/2014			
Chapter 6	1	* Dec 05/2014			
	2	* Dec 05/2014			
	3	* Dec 05/2014			
	4	* Dec 05/2014			
	5	* Dec 05/2014			
	6	May 28/2001			
	7	* Dec 05/2014			
	8	May 28/2001			
	9	May 28/2001			
	10	* Dec 05/2014			
	11	* Dec 05/2014			
	12	* Dec 05/2014			
Chapter 7	1	May 28/2001			
	2	May 28/2001			
	3	May 28/2001			
	4	May 28/2001			
	5	May 28/2001			
	6	May 28/2001			
	7	May 28/2001			
	8	May 28/2001			
	9	May 28/2001			
	10	May 28/2001			
	11	May 28/2001			
	12	May 28/2001			
	13	May 28/2001			
	14	May 28/2001			
Chapter 8	1	May 28/2001			
Chapter 9	1	May 28/2001			
	2	* Dec 05/2014			
	3	* Dec 05/2014			

The asterisk (\*) indicates pages revised, added or deleted by current revision.

Series: 400

**EFFECTIVE**  
**PAGES** Page 2  
Dec 05/2014



**BOMBARDIER**  
AEROSPACE



AIRPORT PLANNING MANUAL

TABLE OF CONTENTS

<b>Title</b>	<b>Page</b>
<b>CHAPTER 1 PREFACE</b>	
Scope	1

Series: 400



**BOMBARDIER**  
AEROSPACE

AIRPORT PLANNING MANUAL

Title	Page
<b>CHAPTER 2 AIRCRAFT DESCRIPTION</b>	
General Information	1
General Airplane Characteristics	3
█ Aircraft Dimensions	5
█ Ground Clearances – General Arrangement	6
█ Maximum Ground Clearances–Standard MLG Tires	7
█ Minimum Ground Clearances–Standard MLG Tires	8
█ Maximum Ground Clearances–Optional MLG Tires	9
█ Minimum Ground Clearances–Optional MLG Tires	10
█ Series 400 (Model 402) Standard Interior Configuration	11
█ Series 400 (Model 402) Optional Interior Configuration	14
█ Passenger – Compartment Cross Section	19
█ Floor loading diagram	21
█ FWD Baggage – Compartment Dimensions (Standard Interior Configuration)	23
█ AFT Baggage Compartment Dimensions (Standard Interior Configuration)	24
█ AFT Baggage Compartment Dimensions (Optional Interior Configuration)	25
█ Nets and Tiedowns (Standard Interior Configuration)	26
█ Nets and Tiedowns (Optional Interior Configuration)	27
█ Door Clearances	28
█ Forward Passenger – Door Clearances	29
█ Aft Passenger – Door Clearances	30
█ Aft Service – Door Clearances	32
█ Forward Baggage Compartment / Forward Type I Emergency Exit – Door Clearances	34
█ Aft Baggage–Compartment – Door Clearances	36
█ Exterior Handles	38
█ Minimum Clearance Between Nacelles and Fuselage	40
█ Aft Baggage Compartment Vertical Dimensions (Typical Configuration)	41
█ Ground Clearances – Empennage and Sill of Aft Baggage Door	42

Series: 400



**BOMBARDIER**  
AEROSPACE



AIRPORT PLANNING MANUAL

<b>Title</b>	<b>Page</b>
<b>CHAPTER 3 AIRCRAFT PERFORMANCE</b>	
General Information	1
Payload/Range at Maximum Cruise Rating and Long Range Cruise	3
Maximum Permissible Take-Off Weight (Wat Limit) – Flaps 5 Degrees	4
Maximum Permissible Take-Off Weight (Wat Limit) – Flaps 10 Degrees	5
Maximum Permissible Take-Off Weight (Wat Limit) – Flaps 15 Degrees	6
Take-Off Runway Length Requirements – Flaps 5 Degrees	7
Take-Off Runway Length Requirements – Flaps 10 Degrees	8
Take-Off Runway Length Requirements – Flaps 15 Degrees	9
Max. Landing Weight – Landing Flaps 10 and Approach Flaps 5 Degrees	10
Max. Landing Weight – Landing Flaps 15 and Approach Flaps 10 Degrees	11
Max. Landing Weight – Landing Flaps 35 and Approach Flaps 15 Degrees	12
Unfactored Landing Distance – Flaps 10 Degrees	13
Unfactored Landing Distance – Flaps 15 Degrees	14
Unfactored Landing Distance – Flaps 35 Degrees	15
Landing – Runway Length Required	16

Series: 400



**BOMBARDIER**  
AEROSPACE

AIRPORT PLANNING MANUAL

<b>Title</b>	<b>Page</b>
<b>CHAPTER 4 GROUND MANEUVERING</b>	
General Information	1
Turning Radii (No Slip Angle)	2
Turning Radii Data (No Slip Angle)	3
Turning Radius at Minimum Power	4
Greater Than 90 Degree Turn – Runway to Taxiway with Tracks	5
90 Degree Turn – Runway to Taxiway with Nose Gear and Cockpit Tracks	6
90 Degree Turn – Taxiway to Taxiway with Nose Gear and Cockpit Tracks	7
Runway Holding Bay (Apron)	8
Aircraft Tie Down Provisions	9
<b>CHAPTER 5 TERMINAL SERVICING</b>	
General Information	1
Aircraft Servicing Arrangement (Typical – No APU)	2
■ Rapid Turnaround Using FWD and AFT Doors	5
■ Rapid Turnaround Using FWD Door Only	6
■ Ground Servicing Point Locations	7
■ Ground Service Connections Data	11
■ Electrical Requirements For Engine Starting	14
■ Ground Towing Requirements	15
■ Ground Air Conditioning Requirements – Pre-Conditioned Airplane	16

Series: 400



**BOMBARDIER**  
AEROSPACE



AIRPORT PLANNING MANUAL

Title	Page
<b>CHAPTER 6 OPERATING CONDITIONS AND NOISE DATA</b>	
General Information	1
Engine Exhaust Temp. Contours at Ground Idle – Top View	2
Engine Exhaust Temp. Contours at Ground Idle – Side View	3
Engine Exhaust Temp. Contours at Flight Idle – Top View	4
Engine Exhaust Temp. Contours at Flight Idle – Side View	5
Engine Exhaust Temp. Contours at Max. T.O. Power – Top View	6
Engine Exhaust Temp. Contours at Max. T.O. Power – Side View	7
Takeoff and Landing Noise Footprint – 3 Degree Approach	8
Takeoff and Landing Noise Footprint – 4 Degrees Approach	9
Ramp Noise Test Results for Optional APU	10
Propeller Slipstream Velocity Contours at Max Takeoff Power	11
Propeller Slipstream Velocity Contours on Ground	12

Series: 400



**BOMBARDIER**  
AEROSPACE

AIRPORT PLANNING MANUAL

<b>Title</b>	<b>Page</b>
<b>CHAPTER 7 PAVEMENT DATA</b>	
General Information	1
Landing Gear Footprint	2
Maximum Pavement Loads	3
Landing Gear Loading on Pavement	4
Flexible Pavement Requirements – CBR (32x8.8–16 Tires)	5
Flexible Pavement Requirements – CBR (34x10.75–16 Tires)	6
Flexible Pavement Requirements – LCN Conversion (32x8.8–16 Tires)	7
Flexible Pavement Requirements – LCN Conversion (34x10.75–16 Tires)	8
Rigid Pavement Requirements – LCN Conversion (32x8.8–16 Tires)	9
Rigid Pavement Requirements – LCN Conversion (34x10.75–16 Tires)	10
Aircraft Classification Number – Flexible Pavement (32x8.8–16 Tires)	11
Aircraft Classification Number – Flexible Pavement (34x10.75–16 Tires)	12
Aircraft Classification Number – Rigid Pavement (32x8.8–16 Tires)	13
Aircraft Classification Number – Rigid pavement (34x10.75–16 Tires)	14
<b>CHAPTER 8 DERIVATIVE AIRCRAFT</b>	
General Information	1
<b>CHAPTER 9 SCALED DRAWINGS OF DASH–8 SERIES 400</b>	
General Information	1
Scaled Dash 8, Series 400 (Model 402) Drawing – 1 in. = 32 ft (1:384)	2
Scaled (Model 402) Drawing – 1in. = 50 ft (1:600), 1in. = 100 ft (1:1200)	3
Scaled Dash 8, Series 400 (Model 402) Drawing – 1:500 and 1:1000 (Metric)	4

Series: 400